Counting Scale KERN CIB









Robust counting scale with large article memory, convenient operating philosophy and checkweighing display, counting resolution up to 30,000 points

Features

- · Innovative counting with tolerance range (Checkweighing): The counting process can be supported visually and/or audibly and this therefore makes portion division, dispensing and grading easier
- Visual signal: the colour of the display changes depending on the counting result (not enough/ok/ too much)
- Audible signal: the frequency of the audible signal changes depending on the counting result (not enough/ok/too much)
- · Ideal for workshops for people with disabilities, particularly loud or quiet environments, where operators change frequently, etc.
- · Three displays for weight display, reference weight, total pieces
- · Precise counting: The automatic reference weight optimisation of reference weight gradually improves the average piece weight value
- · Programmable using numerical key pad:
- Required reference quantity
- Known reference weight

- · Counting results memory: adds up all individual piece counts, result is shown in total weight and total pieces
- · PRE-TARE function for manual subtraction of a known container weight, useful for checking
- · 20 direct price keys for frequently recurring reference weights and PRE-Tare values
- · Memory for 50 reference weights and PRE-Tare values
- · High mobility: thanks to rechargeable battery operation, compact, lightweight construction, it is suitable for the use in several locations
- Two balances in one: Changes from counting mode to weighing mode at the touch of a key
- Energy management: Backlight turns off after 5 sec, can be switched off
- Protective working cover included with delivery

Technical data

- · Large backlit LCD displays, digit height 18 mm
- · Rechargeable battery pack integrated, as standard, operating time up to 160 h without backlight, charging time approx. 14 h
- Dimensions weighing surface, stainless steel, W×D 315×215 mm
- Overall dimensions W×D×H, 350×330×120 mm
- Net weight approx. 3,6 kg
- Permissible ambient temperature -10 $^{\circ}\text{C}/40~^{\circ}\text{C}$

Accessories

- · Protective working cover, scope of delivery 5 items, KERN RIB-A01S05
- · Internal rechargeable battery pack, operating time up to 160 h without backlight, charging time approx. 14 h, KERN GAB-A04

STANDARD



















OPTION				
\mathbf{D}_{I}	AkkS			
+3	DAYS			

Model KERN	Weighing capacity	Readability	Smallest part weight	Counting resolution	Options DAkkS Calibr. Certificate
	[Max] kg	[d] g	(Normal) g/piece	Points	DAkkS KERN
CIB 3K-4	3	0,2	1	30.000	963-127
CIB 6K-4	6	0,5	2	30.000	963-128
CIB 10K-3	15	1	5	30.000	963-128
CIB 30K-3	30	2	10	30.000	963-128

BALANCES & TEST SERVICE 2024

KERN Pictograms





Internal adjusting

Quick setting up of the balance's accuracy with internal adjusting weight (motordriven)



Adjusting program CAL

For quick setting up of the balance's accuracy. External adjusting weight required



EasyTouch

Suitable for the connection, data transmission and control through PC or tablet



Memory

Balance memory capacity, e.g. for article data, weighing data, tare weights, PLU etc.



Alibi memory

Secure, electronic archiving of weighing results, complying with the 2014/31/EU standard.



KERN Universal Port (KUP)

allows the connection of external KUP interface adapters, e.g. RS-232, RS-485, SB, Bluetooth, WIFI, Analogue, Ethernet etc. for the exchange of data and control commands, without installation effort



RS-232 Data interface

To connect the balance to a printer, PC or network



RS-485 Data interface

To connect the balance to a printer, PC or other peripherals. Suitable for data transfer over large distances. Network in bus topology is possible



USB Data interface

To connect the balance to a printer, PC or other peripherals



Bluetooth* Data interface

To transfer data from the balance to a printer, PC or other peripherals



WIFI Data interface

To transfer data from the balance to a printer, PC or other peripherals



Control outputs

(optocoupler, digital I/O) To connect relays, signal lamps, valves, etc.



Analogue interface

to connect a suitable peripheral device for analogue processing of the measurements



Interface for second balance

For direct connection of a second balance



Network interface

For connecting the scale to an Ethernet network



KERN Communication Protocol (KCP)

It is a standardized interface command set for KERN balances and other instruments, which allows retrieving and controlling all relevant parameters and functions of the device. KERN devices featuring KCP are thus easily integrated with computers, industrial controllers and other digital systems



GLP/ISO log intern

The balance displays weight, date and time, independent of a printer connection



GLP/ISO log Printer

With weight, date and time. Only with KERN printers.



Piece counting

Reference quantities selectable. Display can be switched from piece to weight



Recipe level A

The weights of the recipe ingredients can be added together and the total weight of the recipe can be printed out



Recipe level B

Internal memory for complete recipés with name and target value of the recipe ingredients. User guidance through display



Totalising level A

The weights of similar items can be added together and



the total can be printed out Percentage determination



Determining the deviation in % from the target value (100 %)

Weighing units Can be switched to e.g. nonmetric units. See



 \mathcal{Z}

balance model. Please refer to KERN's website for more details



Weighing with tolerance range (Checkweighing)

Upper and lower limiting can be programmed individually, e.g. for sorting and dosing. The process is supported by an audible or visual signal, see the relevant model



Hold function

(Animal weighing program) When the weighing conditions are unstable, a stable weight is calculated as an average value



Protection against dust and water splashes IPxx

The type of protection is shown in the pictogram



Suspended weighing Load support with hook on the underside of the

balance



Battery operation

Ready for battery operation. The battery type is specified for each device



Rechargeable battery pack

Rechargeable set



Universal plug-in power supply

with universal input and optional input socket adapters for A) EU, CH, GB B) EU, CH, GB, US C) EU, CH, GB, US, AUS



Plug-in power supply 230V/50Hz in standard version for EU, CH.

On request GB, USA or AUS version available



Integrated power supply unit

Integrated in balance. 230V/50Hz standard EU. More standards e.g. GB, USA or AUS on request



Weighing principle Strain gauges

Electrical resistor on an elastic deforming body



Weighing principle Tuning fork

A resonating body is electromagnetically excited, causing it to oscillate



Weighing principle Electromagnetic force compensation

Coil inside a permanent magnet. For the most accurate weighings



Weighing principle Single cell technology

Advanced version of the force compensation principle with the highest level of precision



Conformity Assessment

The time required for conformity assessment is specified in the pictogram



DAkkS calibration possible (DKD)

. The time required for DAkkS calibration is shown in days in the pictogram



Factory calibration (ISO)

The time required for Factory calibration is shown in days in the pictogram



Package shipment

The time required for internal shipping preparations is shown in days in the pictogram



Pallet shipment

The time required for internal shipping preparations is shown in days in the pictogram



^{*}The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by KERN & SOHN GmbH is under license. Other trademarks and trade names are those of their respective owners